



Submersible Pond Light

Instructions for Operation • Safety • Warranty



Congratulations! With this pond light you can make your fountain glow, illuminate your pond from within, highlight your waterfall and extend the enjoyment of your water garden into the evening. This light is fully submersible. All models are UL listed for safety.



Installation:

1. Attach the light to a 12v, UL listed transformer. Never plug the light directly into a 110v outlet.
2. To mount the light on its base, unscrew the nut located at the bottom of the light. Attach the connector on the base to the bottom of the light. Screw the nut back to its original position.
3. Place the light in the desired location of your water feature.
4. Be sure that the light is fully submerged.
5. Plug the transformer to ground fault circuit interrupter outlet. For colored light, snap a colored lens on the front of the light.

Warning:

Always disconnect the transformer from the electric outlet before servicing the light to avoid any electrical shock.

Replacing the Bulb:

1. For the replacement of the bulb, please call your EasyPro Dealer to order correct bulb.
2. Disconnect the transformer from the electrical outlet.
3. Remove the light from the water and allow it to dry.
4. Hold the body of the light and unscrew the front head of the light counter clockwise.
5. Remove the clear lens and unplug the bulb/reflector from the socket.
6. Before reassembling the light, clean the clear lens and sealing ring.
7. Press the new bulb into the socket, avoid touching the bulb or inside of the reflector.
8. Place the clear lens on the sealing o-ring ensuring that the sealing o-ring remains seated in the groove.
9. Put the front head on and tightly screw it on clockwise.



This light is warranted against defective material and workmanship for three years (bulb excluded).

Important Safety Instructions:

- Lighted lamp is HOT!! Do not touch the lamp when it is on. This light has not been tested for use in swimming pools or hot tubs. Keep lamp away from any materials which may burn. Do not operate the light fixture with a missing or damaged lens.

Warranty:

- This product is warranted against any mechanical or material defects for a period of three years from the date of purchase (bulbs excluded).
- Replacement liability in all events is limited to the replacing or repairing at our sole discretion any part(s) which are defective in material or workmanship.
- Proof of purchase is required on all claims in the form of an invoice or sales ticket.

Application:

- Warranty covers only properly installed and maintained units.
- Warranty is limited to applications of temperatures between 32° and 86° with a pH range of 5 to 9. Other liquid applications and extreme temperature uses must be approved in advance by us in writing.

Administration:

- Warranty claims must be made by returning defective unit along with proof of purchase to EasyPro at the address to the right.
- **All returned items will be inspected** to determine cause of failure before warranty is approved.
- Warranty does not cover any cost associated with the installation or removal of the products subject to warranty claims.
- We will make a good faith effort for prompt disposition regarding any item in warranty which proves to be defective.

Disclaimer:

Any oral statements about the product made by the seller, the manufacturer, the representatives or any other party do not constitute warranties, should not be relied upon by the user and are not part of the contract for sale. Sellers and manufacturers only obligation, also buyers and users only remedy, shall be for the manufacturer to either replace or repair at the manufacturers sole discretion. Neither seller nor the manufacturer shall be liable for any injury loss or damage. Direct, incidental or consequential (including but not limited to incidental or consequential damages, for lost profits, lost sales, injury to person or property or any other incidental or consequential loss) arising from any cause whatsoever, no matter whether based on warranty, contract negligence or other misuse, and the buyer and user agree that no other remedy shall be available to them. Before using, the buyer and the user shall determine the suitability of the product for the intended use, and assumes all risk and liability whatsoever in connection therewith. The warranty and remedy described in this limited warranty is an exclusive warranty and remedy and in leu of any other warranty or remedy expressed or implied which other warranties and remedies are hereby expressly excluded, including but not limited to any implied warranty of merchantability or fitness for a particular purpose.



**Return
warranty
pumps to:**

**EasyPro
Pond Products
4385 East 110th
Grant, MI 49327**

Be sure to include
return address and
phone number in
package!

